


目录

EDP/DP转GMSL显示模块:MAX96749 3

EDP/DP转GMSL显示模块:MAX96749

MAX96749模块用于将EDP/DP信号转化为GMSL信号。模块配置有标准DP接口及fakra接口。



From:
<https://wiki.yytech.cc/> - YYT Docs

Permanent link:
https://wiki.yytech.cc/doku.php?id=gmsl%E8%A7%86%E9%A2%91%E6%98%BE%E7%A4%BA:edp_dp%E8%BD%ACgmsl%E6%A8%A1%E5%9D%97

Last update: 2025/10/04 11:54

